



CABLE EXTENDER INSTALLATION GUIDE

1 CV620-CABLE-07 Extender Connection



2 CV620-CABLE-06 Extender Connection



* The CV620-CABLE-06 cannot be connected with a Computer and a VS-PTC-200 Controller at the same time