



# CABLE EXTENDER INSTALLATION GUIDE

## 1 CV620-CABLE-07 Extender Connection



## 2 CV620-CABLE-06 Extender Connection



\* The CV620-CABLE-06 cannot be connected with a Computer and a VS-PTC-200 Controller at the same time